




RACE LIGHT



Ref. **JP RL YA001**

OVERVIEW

The Race Light control unit allows you to switch the rear light on and off, enabling it to be used as a Rain Light.

It can be used with either the motorcycle's original rear light or the compatible Jetprime aftermarket rear light.

The rear light is controlled via the supplied push button.

The Race Light also features an optional "Warm Up" function, which causes the rear light to flash when the motorcycle is in neutral.

INSTALLATION

1. Make sure the ignition is turned off.
2. Disconnect the rear light from the motorcycle's original wiring harness.
3. Connect the Race Light (A) connector to the motorcycle's wiring harness in place of the rear light.
4. Connect the Race Light (B) connector to the rear light.
5. Connect the supplied pre-wired control push button to the Race Light (E) connector.
6. (OPTIONAL) Connect the Race Light CAN (C) connector to the motorcycle's OBD connector.

NOTE


The CAN connection is only required to use the Warm Up function.

The Race Light features a bypass connector (D) that replicates the motorcycle's original OBD connector. If a module or accessory is already connected, disconnect it from the OBD connector and connect it to the Race Light bypass connector (D).

If no module or accessory is connected to the motorcycle's OBD connector, leave the bypass connector (D) disconnected.

7. Switch on the motorcycle and check that the system is working correctly.
8. Securely mount the Race Light and the control push button on the motorcycle.

CONNECTORS



OPERATION

Switching the Rear Light On and Off

When the motorcycle is started, the rear light is always off. Press the push button to switch the rear light on, and press it again to switch it off.

Warm Up Function

The CAN connection is required to use the additional Warm Up function.

With the Warm Up function active, the rear light flashes when the motorcycle is in neutral, and automatically switches to steady mode when a gear is engaged. The function takes effect only after the light has been switched on using the push button.

To change the status of the Warm Up function, press and hold the push button for more than 4 seconds. The rear light indicates the new status with a sequence of flashes:

- 4 rapid flashes: Warm Up active.
- 3 rapid flashes: Warm Up inactive.

The setting is stored and remains active for subsequent uses of the Race Light.



JETPRIME S.R.L.

Via Eugenio Montale, 1
41016 Novi di Modena - Rovereto sulla Secchia (MO)
Phone: +39 059 672223 - Email: info@jetprime.it
www.jetprimeshop.it

All JETPRIME products are designed for racing use only and should be installed by an expert.

The manufacturer, importer, or dealer shall not be liable for any damage caused by improper installation or operation of the JETPRIME product.

The warranty is limited to defects recognized by our technical department and to normal use. The warranty is void in case of accident, modification, improper or racing use.

Do not install the product on a motorcycle for which it was not designed or tested by JETPRIME.

The technical specifications of JETPRIME products and related products are subject to change without notice.